

**FINEX**  
FIBER CEMENT EXPERTS

**HEAT-SCREEN  
AND STOVE BASE**

**2<sup>IN</sup>1**  
**HEAT-SCREEN  
AND  
FINISHING  
PANEL**



**ULC COMPLIANT  
LIFETIME WARRANTY**

*Projects For Life!*  
**[www.gofinex.com](http://www.gofinex.com)**

## HEAT SCREENS

### Preparation

Walls must be flat, uniform, dry and free of dirt, dust and grease.

### Installation

Install panels vertically or horizontally, ensuring that they extend at least 12" beyond the sides of the appliance.

The heat screen is placed over the existing wall, supported by furring strips a minimum of 1" thick which have been vertically fastened and aligned on the wall framing system. The 1" space between the existing wall and the Finex panel ensures proper air circulation. Use screws that are long enough to provide a 3/4" anchorage in the framing. Fasten the Finex panels onto the furring strips.

Ensure that there is a gap of at least 1" from the ceiling and at least 3" from the floor to provide adequate air circulation between the existing wall and the Finex panel.



### Cutting

See cutting instructions for FLOORS, BALCONIES AND PATIOS.

### Fastening

Drill holes using a bit with a diameter at least 1/16" bigger than the diameter of the screw to be used.

Use screws appropriate for the substrate material, spacing them every 16" and a minimum of 5/8" from the edge.



**FINEX**  
FIBER CEMENT EXPERTS

[www.gofinex.com](http://www.gofinex.com)

Distributed by:



**BROADLEAF**